DIAGNOSIS AND TESTING - REAR FOG LAMP

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, DISABLE THE AIRBAG SYSTEM BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. DISCONNECT AND ISOLATE THE BATTERY NEGATIVE (GROUND) CABLE, THEN WAIT TWO MINUTES FOR THE AIRBAG SYSTEM CAPACITOR TO DISCHARGE BEFORE PERFORMING FURTHER DIAGNOSIS OR SERVICE. THIS IS THE ONLY SURE WAY TO DISABLE THE AIRBAG SYSTEM. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

Always begin any diagnosis by testing all of the fuses and circuit breakers in the system. Refer to the appropriate wiring information.

REAR FOG LAMP CONDITION CHART

CONDITION	POSSIBLE CAUSES	CORRECTION
REAR FOG LAMP IS ON WITH IGNITION KEY ON	1. Shorted multifunction switch. 2. Shorted steering column clock spring. 3. Shorted fog lamp switch output circuit	1. Test and replace multifunction switch 2. Test and replace clock spring. 3. Repair short to voltage in fog lamp switch output circuit.
REAR FOG LAMP BULB BURNS OUT FREQUENTLY	1. Charging system output too high. 2. Loose or corroded terminals or splices in circuit.	1. Test and repair charging system. 2. Inspect and repair all connectors and splices.
REAR FOG LAMP IS DIM WITH ENGINE RUNNING	1. Charging system output too low. 2. Poor lighting circuit ground. 3. High resistance in fog lamp circuit.	1. Test and repair charging system. 2. Test for voltage drop across ground locations. 3. Test amperage draw of fog lamp circuit.
REAR FOG LAMP FLASHES RANDOMLY	1. Poor lighting circuit ground. 2. High resistance in fog lamp circuit. 3. Faulty multifunction switch. 4. Loose or corroded terminals or splices in circuit.	1. Test for voltage drop across ground locations. 2. Test amperage draw of fog lamp circuit. 3. Replace multifunction switch. 4. Inspect and repair all connectors and splices.
REAR FOG LAMP WILL NOT ILLUMINATE	1. Open fuse for fog lamp. 2. Open battery positive voltage circuit to multifunction switch. 3. No ground at fog lamps. 4. Faulty multifunction switch. 5. Broken connector terminal or wire splice in fog lamp circuit. 6. Faulty or burned out bulb.	1. Test fog lamp circuitry for short to ground and replace fuse. 2. Test and repair open battery positive voltage circuit. 3. Repair circuit ground. 4. Replace multifunction switch. 5. Repair connector terminal or wire splice. 6. Replace bulb.

REMOVAL

(1) Disconnect and isolate the negative battery cable.

(2) Remove the nut that secures the rear fog lamp unit to the rear bumper assembly.

(3) Disconnect the wire harness connector from the rear fog lamp connector (Fig. 13).