INSTALLATION

(1) Position the headlamp leveling switch in front of the steering column cover access hole and connect the switch electrical connector (Fig. 23).

(2) Properly seat the headlamp leveling switch into the steering column cover.

(3) Reconnect negative battery cable.

HEADLAMP LEVELING MOTOR

DIAGNOSIS AND TESTING - HEADLAMP LEVELING SYSTEM

The following test is designed to diagnosis a faulty headlamp leveling system. Refer to Wiring Diagrams for a complete system schematic.

NOTE: Headlamps must be operating properly and the battery must be completely charged (12.4v) prior to testing. It may also be necessary to install battery charger on the vehicles electrical system when performing this test. Refer to the Battery section of the service manual for detailed information.

CONDITION	POSSIBLE CAUSES	CORRECTION
ONE MOTOR DOES NOT OPERATE	1. Poor electrical connection at motor.	1. Check for proper electrical harness connection and circuit terminal tension at the motor.
	2. Open or high resistance in the battery positive voltage circuit to the inoperative leveling motor.	2. Repair the open or high resistance in the leveling motor battery positive voltage circuit.
	3. Open, high resistance in the inoperative leveling motor ground circuit.	3. Repair the open, high resistance in the leveling motor ground circuit.
	4. Open, high resistance, short to voltage or short to ground in the inoperative leveling motor sense circuit.	4. Repair the open, high resistance, short to voltage or short to ground in the motor sense circuit.
	5. Inoperative/Damaged motor.	5. Replace leveling motor.
BOTH MOTORS DO NOT OPERATE	1. No battery positive voltage to the headlamp leveling switch.	1. Repair the open circuit or high resistance in the headlamp leveling switch battery positive voltage circuit.
	2. No battery positive voltage to the headlamp leveling motor.	2. Repair the open circuit or high resistance in the headlamp leveling motor battery positive voltage circuit.
	3. Open, high resistance in the headlamp leveling switch ground circuit.	3. Repair the open, high resistance or short to voltage in the headlamp leveling switch ground circuit.
	4. Open, high resistance in the headlamp leveling motor ground circuit.	4. Repair the open, high resistance or short to voltage in the headlamp leveling motor ground circuit.
	5. Open, high resistance, short to voltage or short to ground in the leveling motor sense circuit.	5. Repair the open, high resistance, short to voltage or short to ground in the motor sense circuit.