LAMPS / LIGHTING - INTERIOR

TABLE OF CONTENTS

page

LAMPS/LIGHTING - INTERIOR
SPECIFICATIONS
INTERIOR LAMPS 34
DOME LAMP UNIT
REMOVAL 34
INSTALLATION 35
DOME LAMP
REMOVAL 35
INSTALLATION 35
DOOR AJAR SWITCH
DESCRIPTION 35
OPERATION 36
DIAGNOSIS AND TESTING - DOOR AJAR SWITCH 36
REMOVAL 36
INSTALLATION 36
REAR WIPER/WASHER SWITCH ILLUMINATION LAMP
REMOVAL 37
INSTALLATION 37

LAMPS / LIGHTING - INTERIOR

SPECIFICATIONS

INTERIOR LAMPS

CAUTION: Do not use bulbs that have a higher candle power than the bulb listed in the Bulb Application Table. Damage to lamp housing and lens can result.

Some components have lamps that can only be serviced by an Authorized Service Center (ASC) after the component is removed from the vehicle.

The following table lists the various lamp trade numbers or part numbers.

LAMP	BULB
Dome (Sound Bar)	912
Under Hood	561
Underpanel Courtesy	906
Instrument Cluster Illumination	103
Instrument Cluster Warning	74
Automatic Transmission Indicator	658

DOME LAMP UNIT

REMOVAL

NOTE: The dome lamp removal procedure is the same for both the right and left side dome lamps.

(1) Disconnect the negative battery cable.

NOTE: The dome lamp lens locating tab is larger than the lens retaining tabs.

(2) Insert a small flat blade between the dome lamp housing and dome lamp lens. Carefully pry the lamp lens from the lamp housing (Fig. 1).

(3) Remove the screws that secure the dome lamp housing to the speaker housing.

(4) Remove the dome lamp housing from the speaker housing and disconnect the wire harness connector from the dome lamp.