8W - 31 TRANSMISSION CONTROL SYSTEM

Component	Page
Brake Lamp Switch	8W-31-2
Brake Transmission Shift Interlock Solenoid	8W-31-2
Clutch Pedal Position Switch	8W-31-8
Data Link Connector	8W-31-8
Fog Lamp Relay	8W-31-3
Front Locker Indicator Switch	8W-31-11
Front Locker Pump	8W-31-10
Front Locker Relay	8W-31-10
Fuse 5	8W-31-3
Fuse 7	8W-31-7
Fuse 10	8W-31-2
Fuse 24	8W-31-10
Fuse Block	8W-31-2, 7
G100	8W-31-3
G105	8W-31-2, 3, 10, 11
G200	8W-31-9, 13
G300	8W-31-2
Input Speed Sensor	8W-31-8
Instrument Cluster	8W-31-2, 9, 11, 12, 13
Left Rear Lamp Assembly	8W-31-7
Output Speed Sensor	8W-31-8
Power Distribution Center	8W-31-3, 10
Powertrain Control Module	8W-31-2, 3, 4, 5, 6, 8, 9, 13
Rear Locker Indicator Switch	8W-31-11
Rear Locker Pump	8W-31-10
Rear Locker Relay	8W-31-10
Right Rear Lamp Assembly	8W-31-7
Tow/Haul Overdrive Off Switch	8W-31-9
Transfer Case Switch	8W-31-2, 13
Transmission Control Relay	8W-31-3, 4, 5
Transmission Range Sensor	8W-31-6, 7, 8
Transmission Solenoid/Pressure Switch Assembly	8W-31-4, 5