8W - 91 CONNECTOR / GROUND / SPLICE LOCATION

TABLE OF CONTENTS

page

CONNECTOR/GROUND/SPLICE LOCATION
DESCRIPTION 1

CONNECTOR / GROUND / SPLICE LOCATION

DESCRIPTION

This section provides illustrations identifying connector, ground, and splice locations in the vehicle. Connector, ground, and splice indexes are provided. Use the wiring diagrams in each section for connector, ground, and splice identification. Refer to the index for the proper figure number. For items that are not shown in this section N/S is placed in the Fig. column.

CONNECTORS

Connector Name/Number	Color	Location	Fig.
A/C Compressor Clutch	BK	At A/C Compressor Clutch	5, 6
A/C Heater Control - C1		Center of Instrument Panel	26, 29
A/C Heater Control - C2		Center of Instrument Panel	26, 29
A/C Heater Control - C3		Center of Instrument Panel	26, 29
A/C High Pressure Switch	BK	Left Side of Engine	5
A/C Low Pressure Switch	GN	Near Powertrain Control Module	5, 6
A/C Pressure Transducer (2.4L)	BK	Near Compressor	6
Airbag Control Module	YL	Front of Floor Pan Tunnel	20
Ambient Temperature Sensor (Compass/Temperature Mirror)		Left Front of Engine Compartment	1
Ambient Temperature Sensor (Engine)		Left Front Engine Compartment	2
Axle Lock Switch(Off Road)		Near Cigar Lighter	26
Back-up Lamp Switch (M/T)	BK	Right Side of Transmission	35, 37
Battery		Rear Engine Compartment	11
Battery Temperature Sensor	BK	Under Battery Tray	10, 12
Blend Door Actuator		On HVAC Harness	N/S
Blower Motor		On HVAC Harness	N/S
Blower Motor Relay	BK	On HVAC Harness	N/S
Blower Motor Resistor Block		On HVAC Harness	N/S
Brake Lamp Switch	GY	Top of Brake Pedal Bracket	22, 30
Brake Transmission Shift Interlock Solenoid	WT	Near Steering Column	30
Brake Warning Indicator Switch	BK	On Brake Master Cylinder	12, 14
C102	GY	Rear Engine Compartment	10, 12