Connector Name/Number	Color	Location	Fig.
Engine Oil Pressure Switch (4.0L)	BK	Right Side of Engine Block	7
Engine Oil Pressure Switch (2.4L)	BK	Below A/C Compressor	N/S
Engine Starter Motor		Left Rear of Engine	3, 8
Engine Starter Solenoid		At Starter Motor	4, 7
Evap/Purge Solenoid	BK	Left Fender Side Shield	13, 14
Front Locker Indicator Switch	BK	Top of Front Differential	33
Front Locker Pump	LT/GY	Top of Locker Pump Bracket	32
Front Washer Pump	BK	Under Washer Fluid Reservoir	1
Front Wiper Motor	BK	At Motor	15
Fuel Injector NO.1 (4.0L)	BK	At Injector	5
Fuel Injector NO.2 (4.0L)	BK	At Injector	5
Fuel Injector NO.3 (4.0L)	BK	At Injector	5
Fuel Injector NO.4 (4.0L)	BK	At Injector	5
Fuel Injector NO.5 (4.0L)	BK	At Injector	5
Fuel Injector NO.6 (4.0L)	BK	At Injector	5
Fuel Pump Module	BK	Above Fuel Tank	40
G Switch	BK	Near T/O for Controller Anti-Lock Brake	20
Generator	BK	Rear of Generator	3, 4, 7, 8
Headlamp Leveling Switch	WT	At Switch	24, 27
Horn	BK	Left Front Fender Side Shield	1
Horn Switch		Rear of Steering Wheel Pad	31
Idle Air Control Motor	BK	Side of Throttle Body	4, 5
Ignition Coil Pack (2.4L)	GY	Right Side of Engine	4, 17
Ignition Coil Pack (4.0L)	BK	Right Rear of Engine	7
Ignition Switch		On Steering Column	30
Input Speed Sensor	BK	Left Center of Trans	16, 36
Instrument Cluster - C1		Rear of Cluster	24, 27
Instrument Cluster - C2		Rear of Cluster	24, 27
Intake Air Temperature Sensor	GY	Rear of Intake Manifold	5
Left Courtesy Lamp	BK	Left Side of Instrument Panel	24, 27
Left Dome Lamp	WT	In Left Speaker Pod	N/S
Left Fog Lamp	BK	At Lamp, See Right	2
Left Front Park/Turn Signal Lamp (Except Export)	BK	At Lamp, See Right	2
Left Front Position Lamp	BK	At Lamp	1
Left Front Speaker	BK	At Speaker	24, 27
Left Front Turn Signal Lamp (Export)	BK	At Lamp, See Right	2
Left Front Wheel Speed Sensor	BK	Left Side of Engine Compartment Near Hydraulic Control Unit	13, 14
Left Headlamp	BK	Rear of Lamp	1