Connector Name/Number	Color	Location	Fig.
Seat Belt Switch (LHD Except Export)	BK	Near Park Brake Switch	20
Sentry Key Immobilizer Module	BK	At Immobilizer	30
Speed Control Servo	BK	Left Side Engine Compartment	13, 14
Subwoofer	LT-GY	Floor Pan	20
Throttle Position Sensor	WT	Side of Throttle Body	5, 18
Tow/Haul Overdrive Off Switch		Center of Instrument Panel	26, 28
Transfer Case Switch	BK	Left Side of Transfer Case	16, 36, 37
Transmission Range Indicator Illumination (PRNDL)	BK	Between Seats	20
Transmission Range Sensor	GN	Left Center of Transmission	16, 36
Transmission Solensid/Pressure Switch Assembly	NAT	Right Center of Transmission	7, 36
Underhood Lamp	BK	Under Hood	10, 12, 18
Variable Line Pressure Sensor		Left Side of Transmission	16, 36
Vehicle Speed Sensor	BK	Left Rear of Transfer Case	16, 36, 37

GROUNDS

Connector Name/ Number	Location	Fig.
G100	Rear Center of Engine Compartment	10, 12
G101	Rear Center of Engine Compartment	10, 12
G102	Left Radiator Closure Panel	1
G103	Right Radiator Closure Panel	2
G104	Near Generator	N/S
G105	Right Rear of Engine Block (4.0L) Near Left Engine Mount (2.4L)	4, 7
G106	Rear of Engine Compartment	3, 11
G107	Left Front of Engine Block	3, 8, 11
G108	Right Rear Engine Block	8
G110 (2.4L)	Near Left Engine Mount	4
G111	Near Right Rear of Engine	N/S
G190	Near Right Headlamp	2
G191	Near Right Headlamp	N/S
G200 (LHD)	Left Rear of Instrument Panel	24
G200 (RHD)	Right Rear of Instrument Panel	27
G201 (LHD)	Left Rear of Instrument Panel	24
G201 (RHD)	Right Rear of Instrument Panel	27
G202 (LHD)	Right Rear of Instrument Panel	25
G202 (RHD)	Left Rear of Instrument Panel	27
G203 (LHD)	Right Rear of Instrument Panel	25