Connector Name/ Number	Location	Fig.
G203 (RHD)	Left Rear of Instrument Panel	27
G204	Center of Instrument Panel	25, 27
G300 (LHD)	Left Kick Panel	22
G300 (RHD)	Right Kick Panel	23
G301 (LHD)	At Base of Center Stack	20
G301 (RHD)	Left Kick Panel	21
G302 (LHD)	Left Kick Panel	22
G302 (RHD)	Right Kick Panel	23
G303	Near Steering Column Mounting Bracket	30

SPLICES

Splice Number	Location	Fig.
S101	Near T/O for Power Distribution Center	10, 12
S102	Near T/O for G100 or Daytime Running Lamp Module	10
S103	Near T/O for G101	10, 12
S105	Left Cowl Panel	22
S106	Near T/O for G100	10
S108	Near T/O for Powertrain Control Module	10, 12
S111	Near T/O for Battery Temperature Sensor or Power Distribution Center	10
S117	Near T/O for Horn	1
S122 (Left)	Near Grommet for Left Front Turn Signal Lamp, See Right	2
S123 (2.4L)	Near T/O for Ignition Coil Pack	N/S
S123 (4.0L)	Near T/O for G105	N/S
S125 (Export) (Right)	Near Grommet for Right Front Turn Signal Lamp	2
S126	Near T/O for C104	7
S127	Rear Engine Compartment	9, 17
S128 (4.0L)	Between Fuel Injector NO. 2 and Fuel Injector NO. 3	5
S128 (2.4L)	Near T/O for C103 on Engine Harness	N/S
S129	Rear of Engine	4, 7, 35
S130 (2.4L)	Near T/O for C103 on Engine Harness	N/S
S130 (4.0L)	Left Rear of Engine	5
S131	Left Rear Engine	7
S132 (2.4L)	Near T/O for Engine Starter Solenoid	4
S132 (4.0L)	Top of Transmission	7, 35
S133 (2.4L)	Near T/O for Input Speed Sensor	4
S133 (4.0L) (A/T)	Trans Harness	7
S134 (4.0L)	Top Front of Engine	5
S134 (2.4L)	Between Engine Starter Solenoid and C182	N/S
S135 (2.4L)	Rear of Engine	4
S135 (4.0L)	In T/O for PCM	9
S136	In Battery harness near PDC	N/S