ENGINE

TABLE OF CONTENTS

page

ENGINE 2.4L 1

page

ENGINE 4.0L 70

ENGINE 2.4L

TABLE OF CONTENTS

page

ENGINE 2.4L
DESCRIPTION . . . 3
DIAGNOSIS AND TESTING
CYLINDER COMPRESSION PRESSURE TEST . . . 3
ENGINE DIAGNOSIS - PERFORMANCE . . . 4
CYLINDER COMBUSTION PRESSURE LEAKAGE TEST . . . 5
ENGINE OIL LEAK INSPECTION . . . 6
ENGINE DIAGNOSIS . . . 7
ENGINE MECHANICAL . . . 7
STANDARD PROCEDURE
REPAIR OF DAMAGED OR WORN THREADS . . . 9
HYDROSTATIC LOCKED ENGINE . . . 9
ENGINE CORE AND OIL GALLERY PLUGS . . . 9
ENGINE GASKET SURFACE PREPARATION . 10
MEASURING BEARING CLEARANCE USING PLASTIGAGE . . . 11
FORM-IN-PLACE GASKETS AND SEALERS . 11
REMOVAL - ENGINE ASSEMBLY . . . 12
INSTALLATION - ENGINE ASSEMBLY . . . 12
SPECIFICATIONS
SPECIFICATIONS - 2.4L ENGINE . . . 13
SPECIFICATIONS - TORQUE . . . 17
SPECIAL TOOLS
2.4L ENGINE . . . 18
AIR CLEANER ELEMENT - 2.4L
REMOVAL - 2.4L . . . 20
INSTALLATION - 2.4L . . . 20
AIR CLEANER HOUSING
REMOVAL . . . 20
INSTALLATION . . . 21
CYLINDER HEAD
DESCRIPTION . . . 21
OPERATION . . . 21
DIAGNOSIS AND TESTING
CYLINDER HEAD GASKET . . . 21
REMOVAL - CYLINDER HEAD . . . 22
CLEANING . . . 22
INSPECTION . . . 23
INSTALLATION - CYLINDER HEAD . . . 23
CAMSHAFT OIL SEAL(S)
REMOVAL . . . 24
INSTALLATION . . . 25
CAMSHAFT(S)
DESCRIPTION . . . 25
OPERATION . . . 26
STANDARD PROCEDURE - CAMSHAFT END-PLAY . . . 26
REMOVAL . . . 26
CLEANING . . . 27
INSPECTION . . . 27
INSTALLATION . . . 27
CYLINDER HEAD COVER
REMOVAL . . . 28
CLEANING . . . 28
INSPECTION . . . 28
INSTALLATION . . . 28
INTAKE/EXHAUST VALVES & SEATS
DESCRIPTION . . . 29
CLEANING . . . 29
VALVE SPRINGS
REMOVAL
REMOVAL - CYLINDER HEAD ON . . . 30
REMOVAL - CYLINDER HEAD OFF . . . 30
INSPECTION . . . 30
INSTALLATION
INSTALLATION - CYLINDER HEAD ON . . . 30
INSTALLATION - CYLINDER HEAD OFF . . . 30
HYDRAULIC LIFTERS
DIAGNOSIS AND TESTING
LASH ADJUSTER (TAPPET) NOISE DIAGNOSIS . . . 31
REMOVAL . . . 31
INSTALLATION . . . 32
ROCKER ARMS
REMOVAL . . . 32
INSPECTION . . . 32
INSTALLATION . . . 32
ENGINE BLOCK
DESCRIPTION . . . 33