STANDARD PROCEDURE
PISTON TO CYLINDER BORE FITTING 33
CYLINDER BORE HONING 33
CLEANING 34
INSPECTION 34
CONNECTING ROD BEARINGS
STANDARD PROCEDURE
CONNECTING ROD - FITTING 34
CRANKSHAFT
DESCRIPTION 35
OPERATION 35
STANDARD PROCEDURE - CRANKSHAFT
END PLAY 35
REMOVAL 36
INSPECTION 36
INSTALLATION 37
CRANKSHAFT MAIN BEARINGS
STANDARD PROCEDURE - MAIN BEARING -
FITTING 38
CRANKSHAFT OIL SEAL - FRONT
REMOVAL 40
INSTALLATION 40
CRANKSHAFT OIL SEAL - REAR
REMOVAL 41
INSTALLATION 42
PISTON & CONNECTING ROD
DESCRIPTION 43
OPERATION 43
REMOVAL 43
INSTALLATION 44
PISTON RINGS
STANDARD PROCEDURE
PISTON RING - FITTING 44
VIBRATION DAMPER
REMOVAL 46
INSTALLATION 46
STRUCTURAL COLLAR
REMOVAL 46
INSTALLATION 47
ENGINE MOUNTING
DESCRIPTION 47
FRONT MOUNT
REMOVAL 47
INSTALLATION 47
REAR MOUNT
REMOVAL 48
INSTALLATION 48
LUBRICATION
DESCRIPTION 48
OPERATION 48
DIAGNOSIS AND TESTING
ENGINE OIL PRESSURE CHECKING 49
OIL
STANDARD PROCEDURE
ENGINE OIL LEVEL CHECK 49
ENGINE OIL AND FILTER CHANGE 49
OIL FILTER
DESCRIPTION 50
REMOVAL 50
INSTALLATION 50
OIL PAN
REMOVAL 50
INSTALLATION 50
OIL PRESSURE SENSOR/SWITCH
DESCRIPTION 51
OPERATION 51
OIL PUMP
REMOVAL 51
DISASSEMBLY 52
CLEANING 52
INSPECTION 52
ASSEMBLY 53
INSTALLATION 53
INTAKE MANIFOLD
DESCRIPTION 54
OPERATION 54
DIAGNOSIS AND TESTING
INTAKE MANIFOLD LEAKS 54
REMOVAL 55
INSPECTION 55
INSTALLATION 55
EXHAUST MANIFOLD
DESCRIPTION 55
OPERATION 56
REMOVAL 56
CLEANING 56
INSPECTION 56
INSTALLATION 56
TIMING BELT COVER(S)
REMOVAL 56
INSTALLATION 56
TIMING BELT AND SPROCKET(S)
REMOVAL
TIMING BELT 58
CRANKSHAFT SPROCKET 59
CLEANING 59
INSTALLATION
CRANKSHAFT SPROCKET 59
TIMING BELT 60
TIMING BELT TENSIONER & PULLEY
REMOVAL 62
INSTALLATION 62
BALANCE SHAFTS AND CARRIER ASSEMBLY
DESCRIPTION 63
OPERATION 64
REMOVAL 64
INSTALLATION 66
BALANCE SHAFT CARRIER
DESCRIPTION 68
OPERATION 69
REMOVAL 69
INSTALLATION 69
BALANCE SHAFT CHAIN
REMOVAL 69
INSTALLATION 69