## ENGINE DIAGNOSIS - PERFORMANCE

| CONDITION | POSSIBLE CAUSE | CORRECTION |
|---|---|---|
| ENGINE WILL NOT START | 1. Weak battery. | 1. Test battery. Charge or replace as necessary. (Refer to 8 - ELECTRICAL/BATTERY SYSTEM - DIAGNOSIS AND TESTING) |
| | 2. Corroded or loose battery connections. | 2. Clean and tighten battery connections. Apply a coat of light mineral grease to terminals. |
| | 3. Faulty starter. | 3. Test starting system. (Refer to 8 - ELECTRICAL/STARTING - DIAGNOSIS AND TESTING) |
| | 4. Faulty coil(s) or control unit. | 4. Test and replace as needed. (Refer to Appropriate Diagnostic Information) |
| | 5. Incorrect spark plug gap. | 5. Set gap. (Refer to 8 - ELECTRICAL/IGNITION CONTROL - SPECIFICATIONS) |
| | 6. Contamination in fuel system. | 6. Clean system and replace fuel filter. |
| | 7. Faulty fuel pump. | 7. Test fuel pump and replace as needed. (Refer to Appropriate Diagnostic Information) |
| | 8. Incorrect engine timing. | 8. Check for a skipped timing belt/ chain. |
| ENGINE STALLS OR IDLES ROUGH | 1. Idle speed too low. | 1. Test minimum air flow. (Refer to Appropriate Diagnostic Information) |
| | 2. Incorrect fuel mixture. | 2. (Refer to Appropriate Diagnostic Information) |
| | 3. Intake manifold leakage. | 3. Inspect intake manifold, manifold gasket, and vacuum hoses. |
| | 4. Faulty ignition coil(s). | 4. Test and replace as necessary. (Refer to Appropriate Diagnostic Information) |