CONDITION	POSSIBLE CAUSES	CORRECTION
	2. Worn camshaft position sensor shaft	2. Remove and repair camshaft position sensor. (Refer to 8 - ELECTRICAL/IGNITION CONTROL/CAMSHAFT POSITION SENSOR - REMOVAL).
	3. Worn or incorrect gapped spark plugs	3. Clean plugs and set gap. (Refer to 8 - ELECTRICAL/IGNITION CONTROL/SPARK PLUG - CLEANING).
	4. Dirt or water in fuel system	4. Clean system and replace fuel filter
	5. Faulty fuel pump	5. Install new fuel pump
	6. Incorrect valve timing	6. Correct valve timing
	7. Blown cylinder head gasket	7. Install new cylinder head gasket
	8. Low compression	8. Test cylinder compression. (Refer to 9 - ENGINE - DIAGNOSIS AND TESTING).
	9. Burned, warped, or pitted valves	9. Install/Reface valves as necessary
	10. Plugged or restricted exhaust system	10. Install new parts as necessary
	11. Faulty ignition coil rail	11. Test and replace, as necessary. (Refer to 8 - ELECTRICAL/IGNITION CONTROL/COIL RAIL - REMOVAL).
ENGINE STALLS OR ROUGH IDLE	1. Carbon build-up on throttle plate	1. Remove throttle body and decarbon. (Refer to 14 - FUEL SYSTEM/FUEL INJECTION/THROTTLE BODY - REMOVAL) for correct procedure.
	2. Engine idle speed too low	2. Check Idle Air Control circuit.
	3. Worn or incorrectly gapped spark plugs	3. Replace or clean and re-gap spark plugs. (Refer to 8 - ELECTRICAL/IGNITION CONTROL/ SPARK PLUG - CLEANING)
	4. Faulty coil rail	4. Test and replace, if necessary. (Refer to 8 - ELECTRICAL/IGNITION CONTROL/COIL RAIL - REMOVAL)
	5. Intake manifold vacuum leak	5. Inspect intake manifold gasket and vacuum hoses. Replace if necessary. (Refer to 9 - ENGINE/MANIFOLDS/INTAKE MANIFOLD - DIAGNOSIS AND TESTING).
ENGINE MISSES ON ACCELERATION	1. Worn or incorrectly gapped spark plugs	1. Replace spark plugs or clean and set gap.
	2. Spark plug cables defective or crossed	2. Replace spark plug cables.
	3. Dirt in fuel system	3. Clean fuel system