(25) Fill the pump reservoir with fluid (Refer to 19 - STEERING/PUMP - STANDARD PROCEDURE).

(26) Inspect the fuel supply line o-ring(s) and replace if necessary. Connect fuel supply line to injectior rail and verify connection by pulling outward on the line.

(27) Install the fuel line bracket to the intake manifold.

(28) Connect the coil rail electrical connectors and oil pressure switch connector.

(29) Connect the following electrical connectors:

- Power steering pressure switch
- Coolant temperature sensor
- Six (6) fuel injector connectors
- Intake air temperature sensor
- Throttle position sensor
- Map sensor
- Crankshaft position sensor
- Oxygen sensor
- Camshaft position sensor
- Generator connector and B+ terminal wire

(30) Connect all previously removed vacuum hoses.

(31) Connect the body ground strap.

(32) Install the throttle, transmission line pressure, and speed control cables to their mounting bracket and connect them to the throttle body.

(33) Connect the heater hoses at the engine thermostat housing and water pump.

(34) Install the fan assembly to the water pump (Refer to 7 - COOLING/ENGINE/FAN DRIVE VISCOUS CLUTCH - INSTALLATION).

(35) Place the fan shroud in position over the fan.

(36) Install the radiator or radiator/condenser (Refer to 7 - COOLING/ENGINE/RADIATOR - INSTALLATION).

(37) Connect the service valves to the A/C compressor ports, if equipped with A/C.

(38) Charge the air conditioner system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE).

(39) Connect the radiator hoses and automatic transmission fluid cooler pipes, if equipped.

(40) Install the fan shroud to the radiator or radiator/condenser (if equipped with A/C).

(41) Install upper radiator support.

(42) Connect the upper radiator hose and tighten the clamp.

(43) Connect the lower radiator hose and tighten the clamp.

(44) Fill crankcase with engine oil (Refer to LUBRICATION & MAINTENANCE - SPECIFICATIONS).

(45) Fill the cooling system (Refer to 7 - COOLING - STANDARD PROCEDURE).

(46) Align the hood to the scribe marks. Install the hood.

(47) Install the air cleaner assembly.

(48) Install the battery and connect the battery cable.

WARNING: USE EXTREME CAUTION WHEN THE ENGINE IS OPERATING. DO NOT STAND IN A DIRECT LINE WITH THE FAN. DO NOT PUT YOUR HANDS NEAR THE PULLEYS, BELTS OR FAN. DO NOT WEAR LOOSE CLOTHING.

(49) Start the engine, inspect for leaks and correct the fluid levels, as necessary.

SPECIFICATIONS

ENGINE - 4.0L

GENERAL DESCRIPTION

DESCRIPTION	SPECIFICATION
Engine Type	In-Line 6 Cylinder
Displacement	4.0 Liters / 4000 cc 242 (Cubic Inches)
Bore	98.4 mm (3.88 in.)
Stroke	86.69 mm (3.413 in.)
Compression Ratio	8.8:1
Firing Order	1-5-3-6-2-4
Lubrication	Pressure Feed-Full Flow-Filtration
Cooling System	Liquid Cooled-Forced Circulation
Cylinder Block	Cast Iron
Crankshaft	Cast Nodular Iron
Cylinder Head	Cast Iron
Camshaft	Cast Iron
Pistons	Aluminum Alloy
Combustion Chamber	Dual-Quench
Connecting Rods	Cast Malleable Iron