| CONDITION | POSSIBLE CAUSE | CORRECTION |
|---|---|---|
| | 6. Leak between exhaust manifold and cylinder head. | 6. Tighten exhaust manifold to cylinder head bolts. |
| | 7. Catalytic converter rusted or blown out. | 7. Replace catalytic converter assy. |
| | 8. Restriction in exhaust system. | 8. Remove restriction, if possible. Replace restricted part if necessary. |
| CAUTION: When servicing and replacing exhaust system components, disconnect the oxygen sensor connector(s). Allowing the exhaust to hang by the oxygen sensor wires will damage the harness and/or sensor. | | |

## SPECIFICATIONS

### TORQUE

| DESCRIPTION | N·m | Ft. Lbs. | In. Lbs. |
|---|---|---|---|
| Bolts, Crossmember to Sill | 42 | 31 | - |
| Nuts, Crossmember to Transmission Mount | 22 | 16 | - |
| Nuts, Exhaust Pipe to Manifold | 31 | 23 | - |
| Nuts/Bolt, Exhaust Manifold to Engine | | | |
| #6&7 | 31 | 23 | - |
| #1,2,3,4,5,8,9,10&11 | 33 | 24 | - |
| Nuts, Exhaust Pipe to Catalytic Converter Flange | 28 | 21 | - |
| Clamp, Tailpipe to Rear Tailpipe Hanger | 27 | 20 | - |
| Oxygen Sensors | 27 | 20 | - |
| Heat Shields | 45 | 33 | - |

## CATALYTIC CONVERTER

### DESCRIPTION

**WARNING: THE NORMAL OPERATING TEMPERATURE OF THE EXHAUST SYSTEM IS VERY HIGH. THEREFORE, NEVER WORK AROUND OR ATTEMPT TO SERVICE ANY PART OF THE EXHAUST SYSTEM UNTIL IT IS COOLED. SPECIAL CARE SHOULD BE TAKEN WHEN WORKING NEAR THE CATALYTIC CONVERTER. THE TEMPERATURE OF THE CONVERTER RISES TO A HIGH LEVEL AFTER A SHORT PERIOD OF ENGINE OPERATION TIME.**

**CAUTION: DO NOT remove spark plug wires from plugs or by any other means short out cylinders. Failure of the catalytic converter can occur due to a temperature increase caused by unburned fuel passing through the converter.**

The stainless steel catalytic converter body is designed to last the life of the vehicle. Excessive heat can result in bulging or other distortion, but excessive heat will not be the fault of the converter. If unburned fuel enters the converter, overheating may occur. If a converter is heat-damaged, correct the cause of the damage at the same time the converter is replaced. Also, inspect all other components of the exhaust system for heat damage.

The catalytic converter and muffler can be separated and serviced individually.

Unleaded gasoline must be used to avoid contaminating the catalyst core.

## REMOVAL

### REMOVAL - 2.4L

**WARNING: THE NORMAL OPERATING TEMPERATURE OF THE EXHAUST SYSTEM IS VERY HIGH. THEREFORE, NEVER ATTEMPT TO SERVICE ANY PART OF THE EXHAUST SYSTEM UNTIL IT IS COOLED. SPECIAL CARE SHOULD BE TAKEN WHEN WORKING NEAR THE CATALYTIC CONVERTER. THE TEMPERATURE OF THE CONVERTER RISES TO A HIGH LEVEL AFTER A SHORT PERIOD OF ENGINE OPERATION TIME.**

**WARNING: IF TORCHES ARE USED WHEN WORKING ON THE EXHAUST SYSTEM, DO NOT ALLOW THE FLAME NEAR THE FUEL LINES.**

**CAUTION: When servicing exhaust system components, disconnect the oxygen sensor connector(s). Allowing the exhaust system to hang by the oxygen sensor harness will damage the wiring and/or sensor.**