

Fig. 3 REAR BUMPER COMPONENTS

1 - BODY
2 - CROSSMEMBER
3 - FRAME
4 - REAR BUMPER
5 - REAR BUMPER
6 - BRACE
7 - REAR BUMPER EXTENSION

INSTALLATION

(1) Position the extension on the bumper.

(2) Install the screws attaching the bumper extension to the bumper.

REAR BUMPER

REMOVAL

(1) Remove the bolt attaching the bumper to frame rail. (Fig. 3)

(2) If equipped, remove the rear tow eye/hook. (Refer to 13 - FRAME & BUMPERS/FRAME/REAR TOW HOOK - REMOVAL)

(3) Disconnect the rear fog lamp electrical connector, if equipped.

(4) Remove the nuts attaching the bumper to the rear frame crossmember.

(5) Separate the bumper from the vehicle.

INSTALLATION

(1) Position the bumper on the vehicle.

(2) Install the nuts attaching the bumper to the rear frame crossmember and tighten to 77 N·m (57 ft. lbs.).

(3) If equipped, install the rear tow eye/hook. (Refer to 13 - FRAME & BUMPERS/FRAME/REAR TOW HOOK - INSTALLATION)

(4) Install the bolt attaching the bumper to frame rail and tighten to 77 N·m (57 ft. lbs.).

(5) Connect the rear fog lamp electrical connectors, if equipped.

FRAME

STANDARD PROCEDURE - FRAME SERVICE

SAFETY PRECAUTIONS AND WARNINGS

WARNING: Use eye protection when grinding or welding metal, serious eye injury can result. Before proceeding with frame repair involving grinding or welding, verify that vehicle fuel system is not leaking or in contact with repair area, personal injury can result. Do not allow open flame to contact plastic body panels. Fire or explosion can result. When welded frame components are replaced, 100% penetration weld must be achieved during installation. If not, dangerous operating conditions can result. Stand clear of cables or chains on pulling equipment during frame straightening operations, personal injury can result. Do not venture under a hoisted vehicle that is not supported on safety stands, personal injury can result.

CAUTION: Do not reuse damaged fasteners, quality of repair would be suspect. Do not drill holes in top or bottom frame rail flanges, frame rail failure can result. Do Not use softer than Grade 3 bolts to replace production fasteners, loosening or failure can result. When using heat to straighten frame components do not exceed 566°C (1050°F), metal fatigue can result. Welding the joints around riveted cross members and frame side rails can weaken frame.

FRAME STRAIGHTENING

When necessary, a conventional frame that is bent or twisted can be straightened by application of heat. The temperature must not exceed 566°C (1050°F). The metal will have a dull red glow at the desired temperature. Excessive heat will decrease the strength of the metal and result in a weakened frame.

Welding the joints around riveted cross members and frame side rails is not recommended.

A straightening repair process should be limited to frame members that are not severely damaged. The replacement bolts, nuts and rivets that are used to join the frame members should conform to the same specifications as the original bolts, nuts and rivets.