Locating Point (PLP), or from center to center of PLP and fastener location.

VEHICLE PREPARATION

Position the vehicle on a level work surface. Using screw or bottle jacks, adjust the vehicle PLP heights to the specified dimension above a level work surface. Vertical dimensions can be taken from the work surface to the locations indicated were applicable.

INDEX

DESCRIPTION	FIGURE
FRAME SIDE VIEW	6
FRAME TOP VIEW	7
FRAME SIDE VIEW LWB	8
FRAME TOP VIEW LWB	9