FUEL SYSTEM

TABLE OF CONTENTS

	page		page
FUEL DELIVERY	1	**FUEL INJECTION**	23

FUEL DELIVERY

TABLE OF CONTENTS

	page		page
FUEL DELIVERY		4.0L	7
DESCRIPTION	1	OPERATION	
OPERATION	1	2.4L	7
STANDARD PROCEDURE		4.0L	7
STANDARD PROCEDURE - DRAINING FUEL TANK	2	REMOVAL	
FUEL SYSTEM PRESSURE RELEASE	2	2.4L	8
SPECIFICATIONS		4.0L	9
FUEL SYSTEM PRESSURE	2	INSTALLATION	
TORQUE	2	2.4L	10
SPECIAL TOOLS		4.0L	10
FUEL SYSTEM	3	**FUEL TANK**	
FUEL PRESSURE REGULATOR		DESCRIPTION	11
DESCRIPTION	3	OPERATION	11
FUEL LEVEL SEND UNIT AND SENSOR		REMOVAL	11
DESCRIPTION	3	INSTALLATION	14
FUEL LINES		**INLET FILTER**	
DESCRIPTION	3	REMOVAL	17
FUEL PUMP		INSTALLATION	17
DESCRIPTION	4	**QUICK CONNECT FITTING**	
FUEL PUMP MODULE		DESCRIPTION	18
DESCRIPTION	5	STANDARD PROCEDURE - QUICK-CONNECT FITTINGS	18
REMOVAL	6		
INSTALLATION	6		
FUEL RAIL/FUEL DAMPER			
DESCRIPTION			
2.4L	6		

FUEL DELIVERY

DESCRIPTION

The fuel delivery system consists of:

- the fuel pump module containing the electric fuel pump, fuel filter/fuel pressure regulator, fuel gauge sending unit (fuel level sensor) and a separate fuel filter located at bottom of pump module
- fuel tubes/lines/hoses
- quick-connect fittings
- fuel injector rail
- fuel injectors
- fuel tank
- fuel tank filler/vent tube assembly
- fuel tank filler tube cap
- check valve(s)
- accelerator pedal
- throttle cable

OPERATION

Fuel is returned through the fuel pump module and back into the fuel tank through the fuel filter/fuel pressure regulator. A separate fuel return line from the engine to the tank is not used.