FUEL INJECTION

TABLE OF CONTENTS

page

FUEL INJECTION
DESCRIPTION . . . 24
SPECIFICATIONS
TORQUE . . . 24
ACCELERATOR PEDAL
REMOVAL . . . 24
INSTALLATION . . . 25
CRANKSHAFT POSITION SENSOR
DESCRIPTION . . . 25
OPERATION . . . 25
REMOVAL
2.4L . . . 26
4.0L . . . 26
INSTALLATION
2.4L . . . 28
4.0L . . . 28
FUEL INJECTOR
DESCRIPTION . . . 28
OPERATION
OPERATION - PCM OUTPUT . . . 29
OPERATION - FUEL INJECTOR . . . 29
REMOVAL . . . 29
INSTALLATION . . . 29
FUEL PUMP RELAY
DESCRIPTION . . . 30
OPERATION . . . 30
REMOVAL . . . 30
INSTALLATION . . . 30
IDLE AIR CONTROL MOTOR
DESCRIPTION . . . 30
OPERATION . . . 30
REMOVAL
2.4L . . . 31
4.0L . . . 31
INSTALLATION
2.4L . . . 31
4.0L . . . 32
INTAKE AIR TEMPERATURE SENSOR
DESCRIPTION . . . 32
OPERATION . . . 32
REMOVAL
2.4L . . . 32
4.0L . . . 32
INSTALLATION
2.4L . . . 33
4.0L . . . 33
MAP SENSOR
DESCRIPTION . . . 33

page

OPERATION . . . 33
REMOVAL
2.4L . . . 34
4.0L . . . 34
INSTALLATION
2.4L . . . 35
4.0L . . . 35
O2 HEATER RELAY
DESCRIPTION . . . 35
OPERATION . . . 35
REMOVAL . . . 35
INSTALLATION . . . 35
O2 SENSOR
DESCRIPTION . . . 35
OPERATION . . . 35
REMOVAL
2.4L . . . 36
4.0L . . . 37
INSTALLATION
2.4L . . . 38
4.0L . . . 38
THROTTLE BODY
DESCRIPTION . . . 38
OPERATION . . . 38
REMOVAL
2.4L . . . 38
4.0L . . . 39
INSTALLATION
2.4L . . . 39
4.0L . . . 39
THROTTLE CONTROL CABLE
REMOVAL
2.4L . . . 40
4.0L . . . 41
INSTALLATION
2.4L . . . 42
4.0L . . . 42
THROTTLE POSITION SENSOR
DESCRIPTION . . . 42
OPERATION . . . 42
REMOVAL
2.4L . . . 42
4.0L . . . 43
INSTALLATION
2.4L . . . 43
4.0L . . . 43