# FUEL INJECTION

## DESCRIPTION

The Powertrain Control Module (PCM) operates the fuel injection system. Refer to Powertrain Control Module in Electronic Control Modules for information.

## SPECIFICATIONS

### TORQUE

| DESCRIPTION | N-m | Ft. Lbs. | In. Lbs. |
|---|---|---|---|
| Accelerator Pedal Bracket Mounting Nuts | 8.5 | - | 75 |
| Engine Coolant Temperature Sensor - 2.4L/4.0L | 11 | - | 96 |
| IAC Motor-To-Throttle Body Bolts - 2.4L/4.0L | 7 | - | 60 |
| Intake Manifold Air Temp. Sensor - 4.0L | 28 | 20 | - |
| MAP Sensor Mounting Screws - 2.4L/4.0L | 3 | - | 25 |
| Oxygen Sensor - 2.4L/4.0L | 30 | 22 | - |
| PCM Mounting Screws | 4 | - | 35 |
| Throttle Body Mounting Bolts - 2.4L/4.0L | 11 | - | 100 |
| Throttle Position Sensor Mounting Screws - 2.4L/4.0L | 7 | - | 60 |
| Vehicle Speed Sensor Mounting Bolt | 2.2 | - | 20 |

# ACCELERATOR PEDAL

## REMOVAL

The accelerator pedal is connected to the throttle body linkage by the throttle cable. The cable is protected by a plastic sheathing and is connected to the throttle body linkage by a ball socket. It is connected to the upper part of the accelerator pedal arm by a plastic retainer (clip) (Fig. 1). This retainer (clip) snaps into the top of the accelerator pedal arm. Retainer tabs (built into the cable sheathing) (Fig. 1) fasten the cable to the dash panel.