PUMP

TABLE OF CONTENTS

page

PUMP
- DESCRIPTION 22
- OPERATION 23
- DIAGNOSIS AND TESTING - PUMP LEAKAGE 23
- STANDARD PROCEDURE - POWER STEERING PUMP - INITIAL OPERATION 23
- REMOVAL
  - REMOVAL - 4.0L 24
  - REMOVAL - 2.4L 24
- INSTALLATION
  - INSTALLATION - 4.0L 24
  - INSTALLATION - 2.4L 24
- SPECIFICATIONS
  - TORQUE CHART 25
- SPECIAL TOOLS
  - POWER STEERING PUMP 25

HOSES
- DESCRIPTION
  - DESCRIPTION - PRESSURE LINE 25
  - DESCRIPTION - RETURN LINE 26
- OPERATION
  - OPERATION - PRESSURE LINE 26
  - OPERATION - RETURN LINE 26

FLUID
- DESCRIPTION 26
- STANDARD PROCEDURE - POWER STEERING FLUID LEVEL CHECKING 26

POWER STEERING PRESSURE SWITCH
- DESCRIPTION 26
- OPERATION 26
- REMOVAL 27
- INSTALLATION 27

PULLEY
- REMOVAL 27
- INSTALLATION 27

RESERVOIR
- REMOVAL
  - REMOVAL - 4.0L 28
  - REMOVAL - 2.4L 28
- INSTALLATION
  - INSTALLATION - 4.0L 28
  - INSTALLATION - 2.4L 28

PUMP

DESCRIPTION

Hydraulic pressure for the power steering system is provided by a belt driven power steering pump (Fig. 1). The pump shaft has a pressed-on high strength plastic drive pulley that is belt driven by the crankshaft pulley. The reservoir is attached to the pump body with spring clips on the 4.0L engine. A remote pump reservoir is used on the 2.4L engine mounted to the fan shroud. The power steering pump is connected to the steering gear by the pressure and return hoses.