AUTOMATIC TRANSMISSION - 42RLE

TABLE OF CONTENTS

page

AUTOMATIC TRANSMISSION - 42RLE
DESCRIPTION 41
OPERATION 42
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - AUTOMATIC TRANSMISSION 47
DIAGNOSIS AND TESTING - ROAD TEST . . . 48
DIAGNOSIS AND TESTING - HYDRAULIC PRESSURE TESTS 49
DIAGNOSIS AND TESTING - CLUTCH AIR PRESSURE TESTS 51
DIAGNOSIS AND TESTING - FLUID LEAKAGE 52
STANDARD PROCEDURE - ALUMINUM THREAD REPAIR 53
REMOVAL 53
DISASSEMBLY 54
ASSEMBLY 70
INSTALLATION 86
SCHEMATICS AND DIAGRAMS - 42RLE TRANSMISSION 89
SPECIFICATIONS
42RLE AUTOMATIC TRANSMISSION 102
SPECIAL TOOLS
42RLE AUTOMATIC TRANSMISSION 103
ACCUMULATOR
DESCRIPTION 107
OPERATION 107
ADAPTER HOUSING SEAL
REMOVAL 108
INSTALLATION 108
BEARINGS
ADJUSTMENTS
BEARING ADJUSTMENT PROCEDURES . . . 108
BRAKE TRANSMISSION SHIFT INTERLOCK MECHANISM
DESCRIPTION 108
OPERATION 109
REMOVAL 109
INSTALLATION 111
ADJUSTMENTS
ADJUSTMENT - BRAKE TRANSMISSION SHIFT INTERLOCK CABLE 111
DRIVING CLUTCHES
DESCRIPTION 112
OPERATION 112
FLUID AND FILTER
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - CAUSES OF BURNT FLUID 112
EFFECTS OF INCORRECT FLUID LEVEL . . 112
FLUID CONTAMINATION 113
STANDARD PROCEDURE
STANDARD PROCEDURE - FLUID LEVEL CHECK 113
STANDARD PROCEDURE - FLUID/FILTER SERVICE 114
STANDARD PROCEDURE - TRANSMISSION FILL 115
GEARSHIFT CABLE
REMOVAL 115
INSTALLATION 116
HOLDING CLUTCHES
DESCRIPTION 117
OPERATION 117
INPUT CLUTCH ASSEMBLY
DISASSEMBLY 117
ASSEMBLY 124
INPUT SPEED SENSOR
DESCRIPTION 134
OPERATION 134
REMOVAL 135
INSTALLATION 135
OIL PUMP
DESCRIPTION 136
OPERATION 136
DISASSEMBLY 136
ASSEMBLY 137
OUTPUT SPEED SENSOR
DESCRIPTION 138
OPERATION 138
REMOVAL 138
INSTALLATION 139
OVERDRIVE SWITCH
DESCRIPTION 139
OPERATION 139
REMOVAL 139
INSTALLATION 140
PLANETARY GEARTRAIN
DESCRIPTION 140
OPERATION 140
OIL PUMP SEAL
REMOVAL 140
INSTALLATION 140
SHIFT MECHANISM
DESCRIPTION 140
OPERATION 141
DIAGNOSIS AND TESTING - SHIFT MECHANISM 141
ADJUSTMENTS - SHIFT MECHANISM 141