SOLENOID
DESCRIPTION 141
OPERATION 142
SOLENOID/PRESSURE SWITCH ASSY
DESCRIPTION 143
OPERATION 143
REMOVAL 144
INSTALLATION 144
TORQUE CONVERTER
DESCRIPTION 145
OPERATION 149
REMOVAL 151
INSTALLATION 151
TRANSMISSION CONTROL RELAY
DESCRIPTION 151
OPERATION 152
TRANSMISSION RANGE SENSOR
DESCRIPTION 152
OPERATION 152
REMOVAL 152
INSTALLATION 153
TRANSMISSION TEMPERATURE SENSOR
DESCRIPTION 153
OPERATION 154
VALVE BODY
DESCRIPTION 154
OPERATION 155
REMOVAL 158
DISASSEMBLY 159
ASSEMBLY 165
INSTALLATION 171