SHIFT LEVER

REMOVAL

(1) Shift transfer case into 4L.
(2) Raise vehicle.
(3) Loosen adjusting trunnion locknut and slide shift rod out of trunnion (Fig. 96). If rod lacks enough travel to come out of trunnion, push trunnion out of torque shaft.
(4) Lower vehicle.
(5) Remove console. (Refer to 23 - BODY/INTERIOR/FLOOR CONSOLE - REMOVAL)
(6) Remove screws attaching lever assembly to floorpan and remove assembly and shift rod (if left attached).