HOOD

TABLE OF CONTENTS

	page
HINGE	
REMOVAL	37
INSTALLATION	37
HOOD	
REMOVAL	37
INSTALLATION	38
ADJUSTMENTS	
ADJUSTMENT	38
HOOD SAFETY LATCH	
REMOVAL	38
INSTALLATION	38

HINGE

REMOVAL

(1) Remove the wiper arms. (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER ARMS - REMOVAL)

(2) Remove the cowl panel and screen. (Refer to 23 - BODY/EXTERIOR/COWL GRILLE AND SCREEN - REMOVAL)

(3) Remove the bolts attaching the hinge to the cowl.

(4) Using a wax pencil, mark the position of the hinge on the hood for installation alignment reference.

(5) Remove the screws attaching the hinge to the hood (Fig. 1).

(6) Separate the hinge from the hood.

INSTALLATION

(1) Prepare and paint the replacement hinge to match the body paint color.

(2) Align the hinge with the installation reference marks on the hood

(3) Install the screws attaching the hinge to the hood and cowl and tighten the to 24 N·m (18 ft. lbs.).

(4) Install the bolts attaching the hinge to the cowl.

(5) Install the cowl panel and screen. (Refer to 23 - BODY/EXTERIOR/COWL GRILLE AND SCREEN - INSTALLATION)

(6) Install the wiper arms. (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER ARMS - INSTALLATION)

HOOD

REMOVAL

(1) Raise and support the hood.

(2) Disconnect the underhood lamp wire harness connector.

(3) Disconnect the windshield washer nozzles.

(4) Disconnect the ground strap.

(5) Mark the position of the hinges on the hood for installation alignment reference.

(6) Remove the screws attaching the hood to the hinge and remove the hood (Fig. 1).

(7) If the hood must be replaced, remove and transfer the insulator panel, hinges, latches, bumpers, brackets, footman loop, hood lamp, support rod, and safety latch to the replacement hood (Fig. 1).