CONTROLS

TABLE OF CONTENTS

page

A/C COMPRESSOR CLUTCH
DESCRIPTION 9
OPERATION 10
DIAGNOSIS AND TESTING
A/C COMPRESSOR CLUTCH COIL 10
STANDARD PROCEDURE
DIODE REPLACEMENT 11
A/C CLUTCH INSPECTION 11
A/C CLUTCH BREAK-IN 11
REMOVAL 12
INSTALLATION 13
A/C CLUTCH RELAY
DESCRIPTION 14
OPERATION 14
REMOVAL 14
INSTALLATION 15
A/C-HEATER CONTROL
DESCRIPTION 15
DIAGNOSIS AND TESTING
VACUUM CONTROL SYSTEM 15
REMOVAL 18
INSTALLATION 20
A/C HIGH PRESSURE SWITCH
DESCRIPTION 20
OPERATION 21
DIAGNOSIS AND TESTING
A/C HIGH PRESSURE SWITCH 21
REMOVAL 21
INSTALLATION 21
A/C LOW PRESSURE SWITCH
DESCRIPTION 21
OPERATION 22
DIAGNOSIS AND TESTING
A/C LOW PRESSURE SWITCH 22
REMOVAL 22
INSTALLATION 23
A/C PRESSURE TRANSDUCER
DESCRIPTION 23
OPERATION 23
DIAGNOSIS AND TESTING
A/C PRESSURE TRANSDUCER 24
REMOVAL 24
INSTALLATION 24

page

BLEND DOOR ACTUATOR
DESCRIPTION 24
OPERATION 25
REMOVAL 25
INSTALLATION 25
BLOWER MOTOR RELAY
DESCRIPTION 26
OPERATION 26
REMOVAL 26
INSTALLATION 27
BLOWER MOTOR RESISTOR
DESCRIPTION 27
OPERATION 27
DIAGNOSIS AND TESTING
BLOWER MOTOR RESISTOR 28
REMOVAL 28
INSTALLATION 28
BLOWER MOTOR SWITCH
DESCRIPTION 29
OPERATION 29
DIAGNOSIS AND TESTING
BLOWER MOTOR SWITCH 29
REMOVAL 29
INSTALLATION 30
MODE DOOR ACTUATORS
DESCRIPTION 30
REMOVAL 30
INSTALLATION 31
RECIRCULATION DOOR ACTUATOR
DESCRIPTION 32
REMOVAL 32
INSTALLATION 32
VACUUM CHECK VALVE
DESCRIPTION 33
OPERATION 33
REMOVAL 33
INSTALLATION 33
VACUUM RESERVOIR
DESCRIPTION 34
OPERATION 34
REMOVAL 34
INSTALLATION 34

A / C COMPRESSOR CLUTCH

DESCRIPTION

The A/C compressor clutch assembly consists of a stationary electromagnetic A/C clutch field coil, a pulley bearing and pulley assembly, and a clutch plate (Fig. 1). These components provide the means to engage and disengage the A/C compressor from the engine accessory drive belt.

The A/C clutch field coil and the pulley bearing and pulley assembly are both retained on the nose of