INSTRUMENT PANEL DEMISTER DUCTS

REMOVAL

WARNING: On vehicles equipped with airbags, disable the airbag system before attempting any steering wheel, steering column, or instrument panel component diagnosis or service. Disconnect and isolate the battery negative (ground) cable, then wait two minutes for the airbag system capacitor to discharge before performing further diagnosis or service. This is the only sure way to disable the airbag system. Failure to take the proper precautions could result in accidental airbag deployment and possible personal injury or death.

NOTE: The two demister ducts can be serviced without removing the instrument panel. However, if either of the demister outlets require servicing, the instrument panel must be removed.

DEMISTER DUCTS

(1) Disconnect and isolate the negative battery cable.

(2) To gain access to the passenger side demister duct, remove the glove box from the instrument panel (Refer to 23 - BODY/INSTRUMENT PANEL/GLOVE BOX - REMOVAL).

(3) To gain access to the driver side demister duct remove the top cover, knee blocker and instrument cluster from the instrument panel (Refer to 23 - BODY/INSTRUMENT PANEL/INSTRUMENT PANEL TOP COVER - REMOVAL), (Refer to 23 - BODY/INSTRUMENT PANEL/KNEE BLOCKER - REMOVAL) and (Refer to 8 - ELECTRICAL/INSTRUMENT CLUSTER - REMOVAL).

(4) Reach through the glove box opening and/or the cluster opening of the instrument panel and disconnect the demister ducts from the demister outlets and the defroster duct as necessary (Fig. 37).