(3) Remove the tape or plugs from the condenser port and the discharge line fitting.

(4) Lubricate a new rubber O-ring seal with clean refrigerant oil and install it on the discharge line fitting. Use only the specified O-ring as it is made of a special material for the R-134a system. Use only refrigerant oil of the type recommended for the A/C compressor in the vehicle.

(5) Connect the A/C discharge line to the A/C condenser.

(6) Install the nut that secures the A/C discharge line to the A/C condenser. Tighten the nut to 12 N·m (105 in. lbs.).

(7) Remove the tape or plugs from the compressor port and the discharge line fitting.

(8) Lubricate a new rubber O-ring seal with clean refrigerant oil and install it on the discharge line fitting. Use only the specified O-ring as it is made of a special material for the R-134a system. Use only refrigerant oil of the type recommended for the A/C compressor in the vehicle.

(9) Connect the A/C discharge line to the A/C compressor.

(10) Install the bolt that secures the A/C discharge line to the A/C compressor. Tighten the bolt to 25 N·m (18 ft. lbs.).

(11) Connect the wire harness connector to the A/C pressure transducer.

(12) Reconnect the negative battery cable.

(13) Evacuate the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM EVACUATE).

(14) Charge the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM CHARGE).

4.0L ENGINE

NOTE: Replacement of the refrigerant line O-ring seals is required anytime a refrigerant line is opened. Failure to replace the rubber O-ring seals could result in a refrigerant system leak.

(1) If removed, install the A/C high pressure switch onto the A/C discharge line. Hand-tighten the switch securely.

(2) Position the A/C discharge line into the engine compartment.

(3) Remove the tape or plugs from the condenser port and the discharge line fitting.

(4) Lubricate a new rubber O-ring seal with clean refrigerant oil and install it on the discharge line fitting. Use only the specified O-ring as it is made of a special material for the R-134a system. Use only refrigerant oil of the type recommended for the A/C compressor in the vehicle.

(5) Connect the A/C discharge line to the A/C condenser.

(6) Install the nut that secures the A/C discharge line to the A/C condenser. Tighten the nut to 12 N·m (105 in. lbs.).

(7) Remove the tape or plugs from the compressor port and the discharge line fitting.

(8) Lubricate a new rubber O-ring seal with clean refrigerant oil and install it on the discharge line fitting. Use only the specified O-ring as it is made of a special material for the R-134a system. Use only refrigerant oil of the type recommended for the A/C compressor in the vehicle.

(9) Connect the A/C discharge line to the A/C compressor.

(10) Install the bolt that secures the A/C discharge line to the A/C compressor. Tighten the bolt to 25 N·m (18 ft. lbs.).

(11) Install the A/C discharge line into the refrigerant line bracket and install the retaining nut. Tighten the nut to 5 N·m (44 in. lbs.).

(12) Connect the wire harness connector to the A/C high pressure switch.

(13) Reconnect the negative battery cable.

(14) Evacuate the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM EVACUATE).

(15) Charge the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM CHARGE).

A / C EVAPORATOR

DESCRIPTION

The A/C evaporator (Fig. 11) for the heating-A/C system is located within the HVAC housing, behind the instrument panel. The A/C evaporator is positioned in the HVAC housing so that all air entering the housing must pass over the evaporator fins before it is distributed through the heating-A/C system ducts and outlets. However, air passing over the evaporator fins will only be conditioned when the A/C compressor is engaged and circulating refrigerant through the A/C evaporator.

The A/C evaporator tubes are connected and sealed to the A/C liquid and suction lines by use of rubber O-rings and quick-connect type fittings

The A/C evaporator can only be serviced by removing and disassembling the HVAC housing.