TABLE OF CONTENTS

1.0 INTRODUCTION 1

1.1 SYSTEM COVERAGE 1
1.2 SIX-STEP TROUBLESHOOTING PROCEDURE 1

2.0 IDENTIFICATION OF SYSTEM 1

3.0 SYSTEM DESCRIPTION AND FUNCTIONAL OPERATION 1

3.1 AIRBAG SYSTEM 1
3.1.1 PASSENGER AIRBAG ON-OFF SWITCH 2
3.1.2 SPECIAL TOOLS 3
3.1.3 DIAGNOSTIC TROUBLE CODES 3
3.1.3.1 ACTIVE CODES 3
3.1.3.2 STORED CODES 3
3.2 AUDIO SYSTEM 4
3.2.1 SATELLITE RADIO (SDARS) 4
3.3 ELECTROCHROMIC COMPASS/TEMPERATURE MIRROR WITH LIGHTS 4
3.4 ELECTRICALLY HEATED SYSTEMS 7
3.4.1 REAR WINDOW DEFOGGER 7
3.5 ELECTRO/MECHANICAL INSTRUMENT CLUSTER (EMIC) 7
3.5.1 SMART CLUSTER FEATURES 7
3.5.2 INSTRUMENT CLUSTER SELF TEST 8
3.6 VEHICLE COMMUNICATION 8
3.7 USING THE DRBIII® 10
3.7.1 DRBIII® ERROR MESSAGES AND BLANK SCREEN 10
3.7.2 DRBIII® DOES NOT POWER UP 10
3.7.3 DISPLAY IS NOT VISIBLE 10

4.0 DISCLAIMERS, SAFETY, WARNING 10

4.1 DISCLAIMERS 10
4.2 SAFETY 10
4.2.1 TECHNICIAN SAFETY INFORMATION 10
4.2.2 VEHICLE PREPARATION FOR TESTING 11
4.2.3 SERVICING SUB-ASSEMBLIES 11
4.2.4 DRBIII® SAFETY INFORMATION 11
4.3 WARNINGS 11
4.3.1 VEHICLE DAMAGE WARNINGS 11
4.3.2 ROAD TESTING A COMPLAINT VEHICLE 11

5.0 REQUIRED TOOLS AND EQUIPMENT 12

6.0 GLOSSARY OF TERMS 12

7.0 DIAGNOSTIC INFORMATION AND PROCEDURES 13

AIRBAG
ACCELEROMETER 1 14
INTERNAL 1 14
OUTPUT DRIVER 1 14
SAFING SENSOR 14
STORED ENERGY FIRING 1 14
STORED ENERGY LOGIC 14