*POOR SOUND QUALITY 94
*SDARS INOP NO CODES 95

CHIME
*CHIME INOPERATIVE AT ALL TIMES 97
*CHIME INOPERATIVE WITH DRIVER SEAT BELT UNFASTENED. 98
*CHIME INOPERATIVE WITH EXTERIOR LAMPS ON AND DRIVER DOOR OPEN .99
*CHIME INOPERATIVE WITH KEY IN IGNITION, DRIVER'S DOOR OPEN 100
*CHIME SOUNDS WITH DRIVER SEAT BELT FASTENED 103
*CHIME SOUNDS WITH DRIVER'S DOOR OPEN, KEY REMOVED 105

COMMUNICATION
*NO RESPONSE FROM AIRBAG CONTROL MODULE 106
*NO RESPONSE FROM CONTROLLER ANTILOCK BRAKE 108
*NO RESPONSE FROM INSTRUMENT CLUSTER 110
*NO RESPONSE FROM PCM (PCI BUS) - NGC 112
*NO RESPONSE FROM PCM (PCM SCI ONLY) - NGC 113
*NO RESPONSE FROM RADIO 116
*NO RESPONSE FROM SATELLITE RADIO RECEIVER 118
*NO RESPONSE FROM SENTRY KEY IMMOBILIZER MODULE 120
*NO RESPONSE FROM TRANSMISSION CONTROL MODULE - NGC 122
*PCI BUS COMMUNICATION FAILURE 125

COMPASS/MINI-TRIP COMPUTER
*COMPASS/TEMP MODULE WILL NOT CALIBRATE 128
*COMPASS/TEMPERATURE MODULE INOPERATIVE. 129
*TEMPERATURE DISPLAY INACCURATE OR INOPERATIVE. 130

ELECTRICALLY HEATED SYSTEMS
*REAR WINDOW DEFOGGER INOPERATIVE. 132
*REAR WINDOW DEFOGGER SWITCH INDICATOR LAMP INOPERATIVE. 135

INSTRUMENT CLUSTER
ACM MESSAGE NOT REC'D BY MIC. 136
AIR BAG LAMP CIRCUIT OPEN 137
AIR BAG LAMP CIRCUIT SHORT 138
CHECKSUM FAILURE 139
PANEL DIMMER OPEN 140
PCM MESSAGE NOT REC'D BY MIC. 142
SKIM MESSAGE NOT REC'D BY MIC 143
*"NO BUS" IN VF DISPLAY 144
*"NO FUSE" IN VF DISPLAY 145
*4WD INDICATOR INOPERATIVE 146
*ABS INDICATOR INOPERATIVE 149
*AIR BAG INDICATOR INOPERATIVE 150
*ALL GAUGES INOPERATIVE. 151
*ANY PCI BUS INDICATOR INOPERATIVE 153
*AXLE LOCK INDICATOR PROBLEMS. 154
*BRAKE WARNING INDICATOR ALWAYS ON 157
*BRAKE WARNING INDICATOR INOPERATIVE 158
*FOG LAMP INDICATOR INOPERATIVE - DOMESTIC 160
*HIGH BEAM INDICATOR INOPERATIVE. 161
*ONE GAUGE INOPERATIVE 162