## Symptom List:

**AIRBAG WARNING INDICATOR OPEN**
**AIRBAG WARNING INDICATOR SHORT**

**Test Note: All symptoms listed above are diagnosed using the same tests. The title for the tests will be AIRBAG WARNING INDICATOR OPEN.**

**When Monitored and Set Condition:**

### AIRBAG WARNING INDICATOR OPEN

When Monitored: With ignition on the ACM monitors the PCI Bus for a message from the MIC containing the airbag warning indicator status. The ACM request the warning lamp status from the MIC once every second.

Set Condition: This DTC will set immediately if the indicator status is OPEN.

### AIRBAG WARNING INDICATOR SHORT

When Monitored: With ignition on the ACM monitors the PCI Bus for a message from the MIC containing the airbag warning indicator status. The ACM request the warning lamp status from the MIC once every second.

Set Condition: This DTC will set immediately if the indicator status is SHORT.

| POSSIBLE CAUSES |
|---|
| MIC, COMMUNICATION FAILURE |
| WARNING INDICATOR |
| ACM, WARNING INDICATOR |
| STORED CODE OR INTERMITTENT CONDITION |
| ACTIVE CODE PRESENT |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Turn the ignition on.<br>Ensure the battery is fully charged.<br>**NOTE: For the purpose of this test, the AECM and ORC modules will be referred to as an ACM.**<br>SELECT ACTIVE or STORED DTC:<br>ACM - ACTIVE DTC<br>Go To 2<br>ACM - STORED DTC<br>Go To 5<br>**NOTE: When reconnecting Airbag system components, the ignition must be turned off and the battery must be disconnected.** | All |