LOSS OF IGNITION RUN - START — Continued

TEST	ACTION	APPLICABILITY
3	Measure the resistance of the Fused Ignition Switch Output Run-Start circuit between the Airbag Run - Start Fuse and ground. Is the resistance below 10.0 ohms? Yes → Go To 4 No → Replace Airbag Run - Start Fuse. Perform __AIRBAG VERIFICATION TEST - VER 1.	All
4	Is this vehicle equipped with a Passenger Airbag On - Off Indicator? Yes → Go To 5 No → Go To 6	All
5	Disconnect the Passenger Airbag On - Off Indicator connector **NOTE: Check connectors - Clean and repair as necessary.** Measure the resistance of the Fused Ignition Switch Output Run-Start Circuit between the On - Off Indicator connector and ground. Is the resistance below 10K ohms? Yes → Go To 6 No → Replace the Passenger Airbag On - Off Switch and Airbag Run - Start Fuse. Perform __AIRBAG VERIFICATION TEST - VER 1.	All
6	**WARNING: TO AVOID PERSONAL INJURY OR DEATH, TURN THE IGNITION OFF, DISCONNECT THE BATTERY AND WAIT TWO MINUTES BEFORE PROCEEDING.** **WARNING: IF THE AIRBAG CONTROL MODULE IS DROPPED AT ANY TIME, IT MUST BE REPLACED. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND PERSONAL INJURY OR DEATH.** Disconnect the Airbag Control Module connector **NOTE: Check connectors - Clean and repair as necessary.** Connect the appropriate Load Tool ACM Adaptor to the ACM connector(s). Measure the resistance of the Fused Ignition Switch Output Run-Start circuit between the ACM Adapter and ground. Is the resistance below 10K ohms? Yes → Repair the Fused Ignition Switch Output Run - Start circuit short to ground. Perform __AIRBAG VERIFICATION TEST - VER 1. No → Replace the Airbag Control Module in accordance with Service Instructions and replace the fuse. Perform __AIRBAG VERIFICATION TEST - VER 1.	All
7	Turn the ignition on. Measure the voltage of the Ignition Switch Output circuit at the Airbag Run - Start fuse. Is the voltage above approximately 6.0 volts? Yes → Go To 8 No → Repair the open Ignition Switch Output Run - Start circuit. Perform __AIRBAG VERIFICATION TEST - VER 1. **NOTE: Reinstall the fuse after performing this test.**	All