## LOSS OF IGNITION RUN - START — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 8 | **WARNING: TO AVOID PERSONAL INJURY OR DEATH, TURN THE IGNITION OFF, DISCONNECT THE BATTERY AND WAIT TWO MINUTES BEFORE PROCEEDING.**<br>**WARNING: IF THE AIRBAG CONTROL MODULE IS DROPPED AT ANY TIME, IT MUST BE REPLACED. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND PERSONAL INJURY OR DEATH.**<br>Disconnect the Airbag Control Module connector.<br>**NOTE: Check connectors - Clean and repair as necessary.**<br>Reinstall the previously removed Airbag Run-Start Fuse.<br>**WARNING: TO AVOID PERSONAL INJURY OR DEATH, TURN THE IGNITION ON, THEN RECONNECT THE BATTERY.**<br>Measure the voltage of the Fused Ignition Switch Output Run-Start Circuit between the Airbag Control Module connector ground.<br>Is the voltage above approximately 4.5 volts?<br>Yes → Go To 9<br>No → Repair open Fused Ignition Switch Output Run-Start circuit. Perform __AIRBAG VERIFICATION TEST - VER 1. | All |
| 9 | **WARNING: TO AVOID PERSONAL INJURY OR DEATH, TURN THE IGNITION OFF, DISCONNECT THE BATTERY AND WAIT TWO MINUTES BEFORE PROCEEDING.**<br>**WARNING: IF THE AIRBAG CONTROL MODULE IS DROPPED AT ANY TIME, IT MUST BE REPLACED. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND PERSONAL INJURY OR DEATH.**<br>If there are no possible causes remaining, view repair.<br>Repair<br>Replace the Airbag Control Module in accordance with Service Instructions.<br>Perform __AIRBAG VERIFICATION TEST - VER 1. | All |