Symptom:
*SDARS INOP NO CODES

POSSIBLE CAUSES
SDARS SUBSCRIPTION
FUSED B+ CIRCUIT
FUSED IGNITION SWITCH OUTPUT
GROUND CIRCUIT OPEN
SATELLITE RADIO RECEIVER

TEST	ACTION	APPLICABILITY
1	Turn the ignition on. With the DRBIII®, read the SDARS subscription status. Does the subscription status read ″subscribed?″ Yes → Go To 2 No → Customer has not subscribed to this feature. No repair at this time. Perform BODY VERIFICATION TEST - VER 1.	All
2	**NOTE: Diagnose and repair any DTCs before continuing.** Disconnect the Satellite Radio Receiver harness connectors. Turn the ignition on and the radio on. Using a 12-volt test light connected to ground, probe the Fused B+ circuit. Does the test light illuminate brightly? Yes → Go To 3 No → Repair the Fused B+ circuit for an open. Check related fuses, if fuse is open, repair short to ground. Perform BODY VERIFICATION TEST - VER 1.	All
3	Disconnect the Satellite Radio Receiver harness connectors. Turn the ignition and the radio on. Using a 12-volt test light connected to ground, probe the Fused Ignition Switch Output circuit. Does the test light illuminate brightly? Yes → Go To 4 No → Repair the Fused Ignition Switch Output circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All
4	Turn the ignition off. Disconnect the Satellite Radio Receiver harness connectors. Using a 12-volt test light connected to 12-volts, probe the Ground circuit. Does the test light illuminate brightly? Yes → Go To 5 No → Repair the Ground circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All