Symptom:

*CHIME INOPERATIVE WITH KEY IN IGNITION, DRIVER'S DOOR OPEN

POSSIBLE CAUSES
OPEN DOOR AJAR GROUND CKT
OPEN/MISSING FUSE 4
DRIVER DOOR AJAR SWITCH
DOOR AJAR SWITCH OUTPUT CIRCUIT OPEN
DRIVER DOOR AJAR SWITCH SENSE CIRCUIT OPEN
INSTRUMENT CLUSTER - DOOR AJAR
IGNITION SWITCH GROUND CIRCUIT OPEN
KEY-IN IGNITION SWITCH OPEN
KEY-IN IGNITION SWITCH SENSE CIRCUIT OPEN
INSTRUMENT CLUSTER - KEY-IN

TEST	ACTION	APPLICABILITY
1	Turn the ignition on. Open the driver door. With the DRB, read the ″DR DOOR AJAR SW″ state. Does the DRB display ″DR DOOR AJAR SW: CLOSED″? Yes → Go To 2 No → Go To 6	All
2	Turn the ignition off. Disconnect the Ignition Switch harness connector. **Note: Ensure the key is in the Ignition Switch Lock Cylinder.** Measure the resistance of the Key-in Ignition Switch with the key in. Is the resistance below 20 ohms? Yes → Go To 3 No → Check the Ignition Lock Cylinder for damage. If OK, replace the Ignition Switch. Perform BODY VERIFICATION TEST - VER 1.	All
3	Turn the ignition off. Disconnect the Ignition Switch harness connector. Measure the resistance of the ground circuit in the ignition switch harness connector. Is the resistance below 5.0 ohms? Yes → Go To 4 No → Repair the ground circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All