Symptom:

*REAR WINDOW DEFOGGER INOPERATIVE

POSSIBLE CAUSES
REAR WINDOW DEFOGGER GROUND CKT
REAR WINDOW DEFOGGER GRID OPEN
REAR WINDOW DEFOGGER RELAY OUTPUT OPEN
FUSED IGNITION SWITCH OUTPUT (RUN) OPEN
FUSED B(+) CKT OPEN
RELAY COIL
RELAY CONTACTS
REAR WINDOW DEFOGGER RELAY CONTROL CIRCUIT OPEN
REAR WINDOW DEFOGGER SWITCH SENSE CKT OPEN
REAR WINDOW DEFOGGER SWITCH SENSE CKT SHORTED TO GROUND
REAR WINDOW DEFOGGER SWITCH SENSE CKT SHORTED TO VOLTAGE
REAR WINDOW DEFOGGER SWITCH
INSTRUMENT CLUSTER

TEST	ACTION	APPLICABILITY
1	Toggle the Rear Defogger switch and listen to the Rear Window Defogger Relay in the PDC. Does the relay click when the switch is pressed? Yes → Go To 2 No → Go To 6	All
2	Turn the ignition off. Open the tailgate. Measure resistance between ground and the Rear Window Defogger Ground circuit. Is the resistance below 5.0 ohms? Yes → Go To 3 No → Repair the Rear Window Defogger Ground Circuit for an open condition. Perform BODY VERIFICATION TEST - VER 1.	All
3	Turn the ignition on. Turn the Rear Window Defogger on. Using a 12-volt test light connected to ground, check the Rear Window Defogger Relay Output circuit at the defogger grid. Does the test light illuminate brightly? Yes → Repair the open in the Rear Window Defogger Grid. Perform BODY VERIFICATION TEST - VER 1. No → Go To 4	All