## Symptom:
## AIR BAG LAMP CIRCUIT OPEN

**When Monitored and Set Condition:**

**AIR BAG LAMP CIRCUIT OPEN**

When Monitored: With the ignition in the Run/Start position, Instrument Cluster in power-up state.

Set Condition: The Instrument Cluster performs an indicator check when the indicator is commanded on or off by the ACM. If an open lamp failure is detected, the Cluster sends this meesage to the ACM.

| POSSIBLE CAUSES |
|---|
| INSTRUMENT CLUSTER |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Turn the ignition on.<br>**NOTE: Ensure the Instrument Cluster and the Air Bag Control Module communicate on the PCI Bus.**<br>**NOTE: The Airbag indicator can only be turned on or off by the ACM. The Instrument Cluster reports the indicator status to the ACM on the PCI Bus.**<br>With the DRBIII®, read DTCs.<br>Does the DRBIII® display Air Bag Lamp Circuit Open?<br>Yes → Replace and configure the Instrument Cluster in accordance with the Service Information.<br>Perform BODY VERIFICATION TEST - VER 1.<br>No → Test Complete. | All |