Symptom:

AIR BAG LAMP CIRCUIT SHORT

When Monitored and Set Condition:

AIR BAG LAMP CIRCUIT SHORT

When Monitored: With the ignition in the Run/Start position, the Instrument Cluster in power-up state.

Set Condition: The Instrument Cluster performs an indicator check when the indicator is commanded on by the ACM. If a shorted lamp failure is detected, the Cluster sends this message to the ACM.

POSSIBLE CAUSES
INSTRUMENT CLUSTER

TEST	ACTION	APPLICABILITY
1	Turn the ignition on. **NOTE: Ensure the Instrument Cluster and the Air Bag Control Module communicate on the PCI Bus.** **NOTE: The Airbag indicator can only be turned on or off by the ACM. The Instrument Cluster reports the status of the indicator to the ACM on the PCI Bus.** With the DRBIII®, read DTCs. Does the DRBIII® display Air Bag Lamp Circuit Shorted? Yes → Replace and configure the Instrument Cluster in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1. No → Test Complete.	All