*4WD INDICATOR INOPERATIVE — Continued

TEST	ACTION	APPLICABILITY
8	Turn the ignition off. Disconnect the Transfer Case Switch harness connector. Connect a jumper wire between the 4WD Indicator circuit and ground. Turn the ignition on. With the DRBIII®, read the 4WD Switch state. Does the DRBIII® display ″Closed″? Yes → Go To 9 No → Repair the 4WD Indicator circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All
9	Turn the ignition off. Disconnect the Transfer Case Switch harness connector. Measure the resistance between ground and the Transfer Case Switch Ground circuit. Is the resistance below 5.0 ohms? Yes → The condition is not present at this time. Monitor DRBIII® parameters while wiggling the related wire harness. Refer to any Technical Service Bulletins (TSB) that may apply. Visually inspect the related wiring harness and connector terminals. Perform BODY VERIFICATION TEST - VER 1. No → Repair the Transfer Case Switch Ground circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All