Symptom:
*ABS INDICATOR INOPERATIVE

POSSIBLE CAUSES
ABS DTC
INSTRUMENT CLUSTER

TEST	ACTION	APPLICABILITY
1	**NOTE: The Instrument Cluster ABS Indicator will not illuminate during the cluster Self Test. The indicator is controlled by PCI Bus messages received from the CAB.** **NOTE: The CAB will command the ABS Indicator on when the ignition is cycled to the Run/Start position.** With the DRBIII®, read DTCs. Does the DRBIII® display any ABS DTCs? Yes → Refer to the Anti-Lock Brake System category and perform the appropriate symptom. Perform BODY VERIFICATION TEST - VER 1. No → Replace the Instrument Cluster in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1.	All