## *ALL GAUGES INOPERATIVE — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 4 | Turn the ignition off.<br>Inspect the #10 Fuse in the Fuse Block.<br>If the fuse is open, replace with proper rated fuse.<br>Turn the ignition on for one minute.<br>Turn the ignition off.<br>Inspect the #10 Fuse in the Fuse Block.<br>Is the fuse open?<br>Yes → Repair the Fused Ignition Switch Output circuit for a short to ground.<br>Perform BODY VERIFICATION TEST - VER 1.<br>No → Go To 5 | All |
| 5 | Turn the ignition off.<br>Disconnect the Instrument Cluster C1 harness connector.<br>Check connectors - Clean/repair as necessary.<br>Turn the ignition on.<br>Measure the voltage between the Fused Ignition Switch Output circuit and ground.<br>Is the voltage above 10.5 volts?<br>Yes → Go To 6<br>No → Repair the Fused Ignition Switch Output circuit for an open.<br>Perform BODY VERIFICATION TEST - VER 1. | All |
| 6 | Turn the ignition off.<br>Disconnect the Instrument Cluster C1 harness connector.<br>Check connectors - Clean/repair as necessary.<br>Measure the resistance between ground and the Instrument Cluster Ground circuit.<br>Is the resistance below 5.0 ohms?<br>Yes → Replace and configure the Instrument Cluster in accordance with the Service Information.<br>Perform BODY VERIFICATION TEST - VER 1.<br>No → Repair the Instrument Cluster Ground circuit for an open.<br>Perform BODY VERIFICATION TEST - VER 1. | All |