*AXLE LOCK INDICATOR PROBLEMS — Continued

TEST	ACTION	APPLICABILITY
8	Place transfer case in 4WD Lo and drive vehicle at less than 2.5 MPH (4 km/h). Press the Axle Locker Switch once to lock the rear axle. With the DRBIII® in Inputs/Outputs, ensure that the Enable 1 and Enable 2 states both read LOW. With the DRBIII® in Inputs/Outputs, ensure that the Rear Lock Request and Rear Lock Return states both read LOCKED. Press the Axle Locker Switch again. Did the Front Axle Lock indicator illuminate? Yes → The condition is not present at this time. Monitor DRBIII® parameters while wiggling the related wire harness. Refer to any Technical Service Bulletins(TSB) that may apply. Visually inspect the related wiring harness and connector terminals. Perform BODY VERIFICATION TEST - VER 1. No → Go To 9	All
9	Place the vehicle in 4WD Lo, operate vehicle at 2.5 MPH (4 km/h) or less. With the DRBIII® in Inputs/Outputs, ensure that the Enable 1 and Enable 2 states read LOW. The Rear Axle Lock indicator must be illuminated. With the DRBIII® in Inputs/Outputs, read the Front Lock Request state. Press the Axle Locker Switch. Did the Front Axle Lock Request change state? Yes → Replace and configure the Instrument Cluster in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1. No → Go To 10	All
10	Turn the ignition off. Disconnect the Axle Locker Switch harness connector. Disconnect the Instrument Cluster C2 harness connector. Measure the resistance of the Front Locker Request circuit between the Axle Locker Switch connector and the Instrument Cluster C2 connector. Is the resistance above 5.0 ohms? Yes → Repair the Front Locker Request circuit for an open. Perform BODY VERIFICATION TEST - VER 1. No → Replace the Axle Lock Switch in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1.	All