Symptom:

***COURTESY LAMPS ON AT ALL TIMES**

POSSIBLE CAUSES
DRIVERS DOOR AJAR SWITCH
DRIVERS DOOR AJAR SWITCH SENSE CIRCUIT SHORT TO GROUND
INSTRUMENT CLUSTER
PANEL LAMPS DIMMER SIGNAL CIRCUIT SHORT TO GROUND
MULTIFUNCTION SWITCH
DOOR AJAR SWITCH OPEN
PASSENGER DOOR AJAR SWITCH SENSE CIRCUIT SHORT TO GROUND
COURTESY LAMP DRIVER CIRCUIT SHORT TO GROUND
INSTRUMENT CLUSTER

TEST	ACTION	APPLICABILITY
1	Close all the doors. Turn the Panel Lamps Dimmer Switch to the MID position. With the DRBIII®, read the Electro/Mech Cluster, I/O's. Does the DRBIII® read CLOSED? Yes → Go To 2 No → Go To 6	All
2	Open the Drivers door. Disconnect the Driver Door Ajar Switch connector. With the DRBIII® select: Body, Electro/Mech Cluster, Input/Output. Read the: Drv Door Ajar Sw - state. Does the DRBIII® show: Open? Yes → Replace the Drivers Door Ajar Switch. Perform BODY VERIFICATION TEST - VER 1. No → Go To 3	All
3	Turn the ignition off. Disconnect the Driver Door Ajar Switch connector. Disconnect the Instrument Cluster connector. Measure resistance of the Driver Door Ajar Switch Sense Circuit from the door ajar switch connector to ground. Is the resistance below 100.0 ohms? Yes → Repair the Drivers Door Ajar Switch Sense Circuit for a short to ground condition. Perform BODY VERIFICATION TEST - VER 1. No → Go To 4	All