*FUEL PRESSURE LEAK DOWN 283
*NO CRANK CONDITION. 284
*NO RESPONSE FROM PCM WITH A NO START CONDITION 287
*START AND STALL CONDITION 290

TRANSMISSION - 42RLE
P0122-THROTTLE POSITION SENSOR/APPS LOW 292
P0123-THROTTLE POSITION SENSOR/APPS HIGH 294
P0124- THROTTLE POSITION SENSOR/APPS INTERMITTENT. 296
P0218-HIGH TEMPERATURE OPERATION ACTIVATED 298
P0562-LOW BATTERY VOLTAGE 300
P0604-INTERNAL TCM 303
P0605-INTERNAL TCM 304
P0613-INTERNAL TCM 305
P0706-CHECK SHIFTER SIGNAL 306
P0711-TRANSMISSION TEMPERATURE SENSOR PERFORMANCE. 312
P0712-TRANSMISSION TEMPERATURE SENSOR LOW. 315
P0713-TRANSMISSION TEMPERATURE SENSOR HIGH 318
P0714-TRANSMISSION TEMPERATURE SENSOR INTERMITTENT 321
P0715-INPUT SPEED SENSOR ERROR 323
P0720-OUTPUT SPEED SENSOR ERROR 327
P0725-ENGINE SPEED SENSOR CIRCUIT 331
P0731-GEAR RATIO ERROR IN 1ST 334
P0732-GEAR RATIO ERROR IN 2ND 336
P0733-GEAR RATIO ERROR IN 3RD 339
P0734-GEAR RATIO ERROR IN 4TH 342
P0736-GEAR RATIO ERROR IN REVERSE. 345
P0740-TCC OUT OF RANGE. 347
P0750-LR SOLENOID CIRCUIT. 349
P0755-2/4 SOLENOID CIRCUIT 353
P0760-OD SOLENOID CIRCUIT 357
P0765-UD SOLENOID CIRCUIT 361
P0841-LR PRESSURE SWITCH SENSE CIRCUIT 365
P0845-2/4 HYDRAULIC PRESSURE TEST FAILURE 369
P0846-2/4 PRESSURE SWITCH SENSE CIRCUIT 373
P0870-OD HYDRAULIC PRESSURE TEST FAILURE 377
P0871-OD PRESSURE SWITCH SENSE CIRCUIT 381
P0884-POWER UP AT SPEED 385
P0888-RELAY OUTPUT ALWAYS OFF 386
P0890-SWITCHED BATTERY 388
P0891-TRANSMISSION RELAY ALWAYS ON 390
P0897-WORN OUT/BURNT TRANSAXLE FLUID. 393
P0944-LOSS OF PRIME. 395
P0992- 2-4/OD HYDRAULIC PRESSURE TEST FAILURE 398
P1652-SERIAL COMMUNICATION LINK MALFUNCTION. 400
P1684-BATTERY WAS DISCONNECTED. 402
P1687-NO COMMUNICATION WITH THE MIC 405
P1694-BUS COMMUNICATION WITH ENGINE MODULE. 407
P1775-SOLENOID SWITCH VALVE LATCHED IN TCC POSITION 409
P1776-SOLENOID SWITCH VALVE LATCHED IN LR POSITION. 413
P1790-FAULT IMMEDIATELY AFTER SHIFT 417
P1793-TRD LINK COMMUNICATION ERROR 418
P1794-SPEED SENSOR GROUND ERROR 421