## OBD II Monitor Operation

| Comprehensive Components Monitor | Major Monitors Non Fuel Control & Non Misfire | Major Monitors Fuel Control & Misfire |
|---|---|---|
| Run constantly | Run Once Per Trip | Run constantly |
| Includes All Engine Hardware Sensors, Switches, Solenoids, etc. | Monitors Entire Emission System | Monitors Entire System |
| Most are One Trip Faults - Usually Turns On The MIL and Sets DTC After One Failure | Most are Two Trip Faults - Turns On The MIL and Sets DTC After Two Consecutive Failure | Two Trip Faults - Turns On The MIL and Sets DTC After Two Consecutive Failure |
| **Priority 3** | **Priority 1 or 3** | **Priority 2 or 4** |
| All Checked For Continuity<br>Open<br>Short To Ground<br>Short To Voltage | Done Stop Testing = Yes<br>Oxygen Sensor Heater<br>Oxygen Sensor Response | **Fuel Control Monitor**<br>Monitors Fuel Control System For:<br>Fuel System Lean<br>Fuel System Rich<br>Requires 3 Consecutive *Fuel System Good Trips* to Extinguish the MIL |
| Inputs Checked For Rationality<br><br>Outputs Checked For Functionality | Catalytic Converter Efficiency Except EWMA up to 6 tests per trip and a one trip fault (SBEC) and a two-trip fault on JTEC | |
| | EGR System Evaporative Emission System (Purge and Leak)<br>Non-LDP<br>or<br>LDP | **Misfire Monitor**<br>Monitors for Engine Misfire At:<br>4 X 1000 RPM Counter (4000 Revs)<br>(Type B)<br>**200 X 3 (600) RPM Counter<br>(Type A) |
| Requires 3 Consecutive Good Trips to Extinguish the MIL* | Requires 3 Consecutive Good Trips to Extinguish the MIL* | Requires 3 Consecutive *Good Trips* To Extinguish the MIL |
| | | **Type A misfire is a one trip failure on pre-1999, 2 Trip failure on 1999 and later. The MIL will illuminate at the first or second failure, based on MY. |

***40 Warm Up Cycles** are required to erase DTCs after the MIL has been extinguished.