P0131-O2 SENSOR 1/1 CIRCUIT LOW VOLTAGE — Continued

TEST	ACTION	APPLICABILITY
1	Start the engine. Allow the engine to reach normal operating temperature. **NOTE: When diagnosing this DTC, diagnose the O2 Sensor that set the DTC.** With the DRBIII®, read the O2 Sensor voltage. Is the voltage below 2.52 volts? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	Turn the ignition off. Disconnect the O2 Sensor harness connector. Ignition on, engine not running. With the DRBIII®, monitor the O2 Sensor voltage. Is the O2 Sensor voltage above 4.8 volts? Yes → Go To 3 No → Go To 4	All
3	Measure the voltage on the O2 Return circuit at the O2 Sensor harness connector. Is the voltage at 2.5 volts? Yes → Replace the O2 Sensor. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 4	All
4	Turn the ignition off. Disconnect the PCM harness connectors. Measure the resistance between ground and the O2 Return circuit at the O2 Sensor harness connector. Is the resistance below 100 ohms? Yes → Repair the short to ground in the O2 Return circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 5	All
5	**NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.** Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits. If there are no possible causes remaining, view repair. Repair Replace and program the Powertrain Control Module per Service Information. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All