P0171-FUEL SYSTEM 1/1 LEAN — Continued

TEST	ACTION	APPLICABILITY
1	Diagnose all other trouble codes before continuing. **NOTE: Check for contaminants that may have damaged an O2 Sensor: contaminated fuel, unapproved silicone, oil and coolant.** Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	**WARNING: The fuel system is under constant pressure (even with the engine off). Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.** Install a fuel pressure gauge to the fuel rail. Ignition on, engine not running. With the DRBIII®, actuate the ASD Fuel System test and observe the fuel pressure gauge. **NOTE: Fuel pressure specification is 407 KPa +/- 34 KPa (59 psi +/- 5 psi).** Turn the ignition off. Choose a conclusion that best matches your fuel pressure reading. Within Specification Go To 3 Above Specification Replace the fuel filter/pressure regulator. Perform POWERTRAIN VERIFICATION TEST VER - 5. Below Specification Go To 13 **Caution: Stop All Actuations.**	All
3	Start the engine. Allow the engine to reach normal operating temperature. **NOTE: If one of the O2 Sensors Signal or Return circuit is shorted to ground the DRBIII® will display all O2 Sensor voltage readings low. The O2 Sensor that is shorted to ground will display a voltage reading near or at 0 volts.** **NOTE: If one of the O2 Sensors Signal or Return circuit is shorted to voltage, the DRBIII® will display all O2 Sensor voltage readings high. It is important to diagnose the O2 Sensor that set the DTC.** **NOTE: After the repairs have been made, verify proper O2 Sensor operation. If all the O2 Sensor voltage readings have not returned to normal, follow the diagnostic procedure for the remaining O2 Sensors.** With the DRBIII®, monitor all the O2 Sensor voltage readings. Is the voltage switching between 2.5 and 3.4 volts for all of the O2 Sensors? Yes → Go To 4 No → Go To 10	All