Symptom List:

P0201-FUEL INJECTOR NO.1 CIRCUIT
P0202-FUEL INJECTOR NO.2 CIRCUIT
P0203-FUEL INJECTOR NO.3 CIRCUIT
P0204-FUEL INJECTOR NO.4 CIRCUIT
P0205-FUEL INJECTOR NO.5 CIRCUIT
P0206-FUEL INJECTOR NO.6 CIRCUIT

Test Note: All symptoms listed above are diagnosed using the same tests. The title for the tests will be P0201-FUEL INJECTOR NO.1 CIRCUIT.

When Monitored and Set Condition:

P0201-FUEL INJECTOR NO.1 CIRCUIT

When Monitored: With battery voltage greater than 11.9981 volts. Auto Shutdown Relay energized. Engine speed less than 3008 rpm.

Set Condition: No inductive spike is detected after injector turn off.

P0202-FUEL INJECTOR NO.2 CIRCUIT

When Monitored: With battery voltage greater than 11.9981 volts. Auto Shutdown Relay energized. Engine speed less than 3008 rpm.

Set Condition: No inductive spike is detected after injector turn off.

P0203-FUEL INJECTOR NO.3 CIRCUIT

When Monitored: With battery voltage greater than 11.9981 volts. Auto Shutdown Relay energized. Engine speed less than 3008 rpm.

Set Condition: No inductive is detected after injector turn off.

P0204-FUEL INJECTOR NO.4 CIRCUIT

When Monitored: With battery voltage greater than 11.9981 volts. Auto Shutdown Relay energized. Engine speed less than 3008 rpm.

Set Condition: No inductive spike is detected after injector turn off, and with no other injectors on.

P0205-FUEL INJECTOR NO.5 CIRCUIT

When Monitored: With battery voltage greater than 11.9981 volts. Auto Shutdown Relay energized. Engine speed less than 3008 rpm.

Set Condition: No inductive spike is detected after injector turn off.