P0300-MULTIPLE CYLINDER MISFIRE — Continued

TEST	ACTION	APPLICABILITY
4	Turn the ignition off. Remove the Ignition Coil. Connect the Ignition Coil harness connector. **NOTE Before continuing, inspect the Ignition Coil for the following conditions. If a problem is found, replace the Ignition Coil. Damage or Carbon Tracking on the Coil or the spark plug insulator boot.** Install a spark tester on the Ignition Coil. While cranking the engine observe the spark coming from the spark tester. **NOTE: A crisp blue spark that is able to jump the gap of the spark tester should be generated.** Is good spark present? Yes → Go To 5 No → Go To 14 **NOTE: Connect the Fuel Injector harness connector before continuing.**	All
5	Turn the ignition off. Remove the Spark Plug. Inspect the Spark Plug for the following conditions. - Cracks - Carbon Tracking - Foreign Material - Gap size out of specifications - Loose or broke electrode **NOTE: Lightly tap the bottom of the spark plug on a solid surface. The electrode in the spark plug should not move.** Were any of the above condition present? Yes → Replace the Spark Plug. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 6	All
6	**Warning: The fuel system is under a constant pressure (even with the engine off). Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.** Install a fuel pressure gauge. Start the engine and observe the fuel pressure reading. **NOTE: Fuel pressure specification is 407 KPa +/- 34 KPa (59 psi +/- 5 psi).** Choose a conclusion that best matches your fuel pressure reading. Within Specification Go To 7 Below Specification Go To 12 Above Specification Replace the fuel filter/pressure regulator. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All