## Symptom:

## P0340-CAMSHAFT POSITION SENSOR CIRCUIT

**When Monitored and Set Condition:**

**P0340-CAMSHAFT POSITION SENSOR CIRCUIT**

When Monitored: Engine cranking/running. Battery voltage greater than 10 volts.

Set Condition: At least 5 seconds or 2.5 engine revolutions have elapsed with crankshaft position sensor signals present but no camshaft position sensor signal.

| POSSIBLE CAUSES |
|---|
| INTERMITTENT CMP SIGNAL |
| INTERMITTENT CKP SIGNAL |
| (F856) 5-VOLT SUPPLY CIRCUIT SHORTED TO VOLTAGE |
| (F856) 5-VOLT SUPPLY CIRCUIT OPEN |
| (F856) 5-VOLT SUPPLY CIRCUIT SHORTED TO GROUND |
| (K44) CMP SIGNAL CIRCUIT SHORTED TO VOLTAGE |
| (K44) CMP SIGNAL CIRCUIT OPEN |
| (K44) CMP SIGNAL CIRCUIT SHORTED TO GROUND |
| (K44) CMP SIGNAL SHORTED TO THE (F856) 5-VOLT SUPPLY CIRCUIT |
| (K900) SENSOR GROUND CIRCUIT OPEN |
| CAMSHAFT POSITION SENSOR |
| PCM |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Crank the engine.<br>Ignition on, engine not running.<br>With the DRBIII®, read DTCs and record the related Freeze Frame data.<br>Is the Good Trip Counter displayed and equal to zero?<br>Yes → Go To 2<br>No → Go To 14 | All |
| 2 | Turn the ignition off.<br>Disconnect the CMP Sensor harness connector.<br>Ignition on, engine not running.<br>Measure the voltage on the (F856) 5-volt Supply circuit in the CMP Sensor harness connector.<br>Is the voltage between 4.5 and 5.2 volts?<br>Yes → Go To 3<br>No → Go To 10 | All |