P0440-GENERAL EVAP SYSTEM FAILURE — Continued

TEST	ACTION	APPLICABILITY
6	To continue testing you will need Miller Tool #8404 Evaporative Emission Leak Detector (EELD). **WARNING: Keep lit cigarettes, sparks, flames, and other ignition sources away from the test area to prevent the ignition of explosive gases. Keep the test area well ventilated.** **NOTE: The fuel tank should have between 20% and 80% of fuel tank capacity to properly test the Evap system.** Connect the red power lead of EELD to the battery positive terminal and the black ground lead to battery negative terminal. **NOTE: See Charts and Graph support material EELD Calibration Setup for an example.** Block the vent hose of the EVAP Canister. Connect shop air to the EELD. Set the smoke/air control switch to AIR. Insert the tester's AIR supply tip (clear hose) into the .040 orifice on the tester's control panel. Press the remote smoke/air start button. Position the red flag on the air flow meter so it is aligned with the indicator ball. When the calibration is complete, release the remote button. The EELD flow meter is now calibrated in liters per minute. Install the service port adapter #8404-14 on the vehicle's service port (if equipped) or install the #8404-ADP into the filter line. Connect the Air supply hose from the EELD to the service port (if equipped) or to the #8404-ADP adapter. Press the remote button to activate AIR flow. **NOTE: Larger volume fuel tanks, lower fuel levels or if the vehicle is equipped with a Flow Management Valve, this may indicate high flow and will require 4 to 5 minutes to fill.** Compare the flow meter indicator ball reading to the red flag. ABOVE the red flag indicates a leak present. BELOW the red flag indicates a sealed system. Is the indicator ball above the red flag? Yes → Go To 7 No → Go To 8	All